

# Remote Control User Manual

The compact and elegant remote control is easy to carry. It is designed to fit on a key chain, a purse, a pocket or to be hidden in the car sun visor. This remote control act as multi-purpose key for arming, disarming, arming stay, and emergency call.


## LED Indication:

### LED Flashes:

Transmitting the signal to control panel.

### Low LED Light:

Low battery, please replace the battery immediately.



## Specifications:

Power Supply: DC 3V(1pc CR2032 button cell battery)

Transmitting:  $\leq 6\text{mA}$

Transmitting Distance:  $\leq 80\text{m}$  (in open area)

Transmitting Frequency: 315MHz/433MHz ( $\pm 75\text{KHz}$ )

Housing Material: ABS plastic

Working Temperature:  $-10^{\circ}\text{C}$ - $55^{\circ}\text{C}$



Humidity: Up to 80% (non-condensing)

Dimension(L/W/H): 35x70x12 mm

## Button Manual

---

### Arm

Press the **arm** button to arm the system before leaving your home, arming LED (left) flashes once, any detectors (in Normal Zone)

triggered will activate the system to alarm immediately. The system simultaneously calls the preset phone numbers.



### Disarm

Press the **disarm** button before entering your home, disarming LED (right) flashes once. Then you are able to move freely in your home without

triggering the alarm. In the event of alarm, you can press this button to disarm the system and silence the siren.




### Mute Mode

Press **stay arm** button, then press **arm** or **disarm** button within 3 seconds to enter into arming or disarming state in mute mode without disturbing someone.

### Stay Arm (Home Mode)

Press the **stay** button, arming LED (left) flashes once, the siren beeps once, system is in stay arm mode. The accessories in home

mode are disarmed, this allows the user to move freely at home, while the rest of the system is fully armed, the accessories in normal zones will activate an immediate alarm when triggered.



### Emergency Call

Once there's an emergency situation, no matter what state the alarm system is in, press **SOS** button once for help, both LED flashes once, the system immediately goes into an alarm condition and notify your family.

